

65 Redding Rd. Unit 874  
Georgetown, CT 06829  
Phone: 203-659-0456  
FAX: 203-549-0409  
E-Mail: [info@TRASSIG.COM](mailto:info@TRASSIG.COM)  
Web: [www.TRASSIG.com](http://www.TRASSIG.com)



**Trassig**

“The Playground People”

## PIP Rebinder Instructions

### Installation Procedure

1. Insure that the poured in place surface is clean from debris and loose rubber granules. We suggest using a leaf blower to remove all debris.
2. Make sure **you mix the top coat liquid thoroughly** before use.
3. Use a medium thickness nap roller to roll the top coat onto surface.
4. Push the roller into the rubber surface so that the binders makes its way between the granules
5. Let cure for 48 hours.

### Additional Guidelines/Notes

- After initial installation, the PIP surface may appear to have a slight “gloss.” This will fade very quickly.
- Also after initial installation, the surface will be slightly harder due to a new layer of binder being applied, this is not permanent, and will return to normal after several days.